

INSERT LOOSE SPLINE FOR GENERAL SLAB-TO-SLAB ALLIGNMENT

WHEN ALLIGNED, PUSH SLABS TOGETHER
FITTING SPLINE BETWEEN. INSERT DRAWBOLTS
FROM BELOW, USE APPROPRIATE TOOL TO PULL
DRAWBOLTS TO SNUG. DO NOT OVERTIGHTEN.

GREEN MOUNTAIN BUTCHER BLOCK JOINT FITTING INSTRUCTIONS